

Jasper

Full Assembly Instructions

K I N G

Assembly | User Guide


Two people are required for safe assembly

Opening Boxes:


DO NOT use a knife to open the King boxes as you may damage your furniture. Peel off the tape, then lift & separate the cardboard flaps to open.

Assemble your furniture by following the instructions below.

1




2




3

 x8


 x2

 x4




a



b




4


 x1 (5mm)


5


a



b




c




Jasper Alternate Features

K I N G

Back Rest: Bed Position




Flat Shelf Assembly




Shelf Light Charge Assembly

1





⚠ Do not connect shelf to power until assembly is complete.


⚠ Ensure touch-activated light is turned **OFF** before flat shelf assembly.




2






3



Light On / Off





Smart Accessory Assembly




Jasper Storage
Storage Assembly


K I N G



3




4




Foot Grip Pads


1





2




Right Hand Storage




Left Hand Storage




2



3




4




Storage Platform Reconfigure - Chaise


Left Hand Storage




Right Hand Storage




1




2


 x1 (6mm)




3




4



5




6





Jasper
Media Consoles
Assembly | User Guide

K I N G

MC 52





MC 38





Features


Drawer



Storage



Base Removal for Subwoofer



Concealing Cables

